

Chord Bar Arrangements for Oscar Schmidt Autoharps

Note: The top row of chord bars are towards the short side of the instrument, the bottom chord bars are towards the long side of the instrument.

Identifying Chords: Minor chords are denoted in the below chart by the letter "M" after the note name. Dominant seven chords are denoted by the number "7" after the note name. All bars without a letter "M" or number "7" after the note name are major.

21 Chord							
E b	B b	F	C	G	D	A	
F7	C7	G7	D7	A7	E7	B7	
A b	B b7	C m	G m	D m	A m	E m	
15 Chord							
D	G m	A7	D m	E7	A m	D7	
E b	F7	B b	C7	F	G7	C	G

*21 Chord models are designed so that you can arrange the chord bars to your preference. You can create your own arrangement by simply arranging the chord bar to the position that you desire. Fit the chord buttons so that they align with the holes in the cover.

*15 Chord models are limited to few changes in the arrangement. Chord bars can only be moved within the row that they presently appear.

Example: you could change the D and the Dm in the upper row but not the E7 with the Eb.



15 Chord Model



21 Chord Model